

PDHonline Course L130 (5 PDH)

FEMA's Flood Insurance Study Report (FIS) - Understanding and Utilizing This Resource

Instructor: Jonathan Terry, P.L.S.

2020

PDH Online | PDH Center

5272 Meadow Estates Drive Fairfax, VA 22030-6658 Phone: 703-988-0088 www.PDHonline.com

An Approved Continuing Education Provider

Welcome to:

FEMA's FIS Tutorial

Screen-captures of FEMA's well-thought-out and carefully presented tutorial on the:

Flood Insurance Study


FEMA FIS TUTORIAL IS FOUND ON THE WEB AT: http://www.fema.gov/media/fhm/fis/ot fis.htm


TABLE OF CONTENTS


Page	Description
12	Welcome
13	What is a Flood Insurance Study?
14	Obtaining Flood Insurance Studies
15	What is found in this tutorial?
16	1.0 Introduction
16	1.1 Purpose of Study
17	1.2 Authority and Acknowledgements
18	1.3 Coordination
19	2.0 Area Studied
19	2.1 Scope of Study
21	2.2 Community Description
22	2.3 Principal Flood Problems
23	2.4 Flood Protection Measures
29	3.0 Engineering Methods
30	3.1 Hydrologic Analyses
41	3.2 Hydraulic Analyses
46	3.3 Wave Height Analyses
67	4.0 Floodplain Management Applications
67	4.1 Floodplain Boundaries
68	4.2 Floodways
70	Floodways (Floodway Data Table)
82	5.0 Insurance Applications
82	6.0 Flood Insurance Rate Map
83	7.0 Other Studies
83	8.0 Location of Data
83	9.0 Bibliography
84	10.0 Revisions
85	Flood Profiles (FIRM Animation)
90	Flood Profiles (FIS Flood Profile Animation)
94	Conclusion
95	Sample of the Certificate provided on FEMA's site at conclusion of tutorial.


Glossary (Terms defined on the Glossary pull-down menu of the FIS tutorial.


97




























































































































































































CLICKING ON THE MOVIE CAMERA ICON ON THE ABOVE SLIDE BRINGS UP THIS SLIDE:




CLICKING ON CROSS SECTION HEADING BRINGS UP THIS SLIDE:




CLICKING ON **DISTANCE** HEADING BRINGS UP THIS SLIDE:




CLICKING ON WIDTH - (FEET) HEADING BRINGS UP THIS SLIDE:




CLICKING "NEXT" ON THE ABOVE SLIDE BRINGS UP THIS SLIDE:




CLICKING ON SECTION AREA (SQUARE FEET) HEADING BRINGS UP THIS SLIDE:




CLICKING ON MEAN VELOCITY (FEET PER SECOND) HEADING BRINGS UP THIS SLIDE:




CLICKING ON REGULATORY HEADING BRINGS UP THIS SLIDE:




CLICKING ON WITHOUT FLOODWAY HEADING BRINGS UP THIS SLIDE:




CLICKING ON WITH FLOODWAY HEADING BRINGS UP THIS SLIDE:




CLICKING ON INCREASE HEADING BRINGS UP THIS SLIDE:
















CLICKING THE MOVIE CAMERA IN THE ELLIPSE BRINGS UP THE FOLLOWING SERIES OF SLIDES














CLICKING THE MOVIE CAMERA IN THE ELLIPSE BRINGS UP THE FOLLOWING SERIES OF SLIDES


THE ANIMATION DRAWS THE RED LINES ON THE FOLLOWING 3 SLIDES












THE FEMA FIS TUTORIAL PROVIDES A VERY PROFESSIONAL LOOKING CERTIFICATE THAT YOU CAN PRINT OUT AT THE CONCLUSION OF YOUR SESSION.

TO OBTAIN YOUR CONTINUING EDUCATION CREDIT FROM PDH ONLINE, YOU MUST COMPLETE AND PASS THE QUIZ ON THE PDH ONLINE SITE.



GLOSSARY ENTRIES PROVIDED ON THE TUTORIAL'S "GLOSSARY" PULL-DOWN MENU:

Base Flood

The flood having a 1-percent chance of being equaled or exceeded in any given year, also known as the 100-year flood. The base flood, which is the standard used by most Federal and state agencies, is used by the National Flood Insurance Program (NFIP) as the standard for floodplain management and to determine the need for flood insurance. A structure located within a special flood hazard area on a NFIP map has a 26-percent chance of suffering flood damage during the term of a 30-year mortgage.

Base Flood Elevation (BFE)

The height of the base flood usually in feet, in relation to the National Geodetic Vertical Datum of 1929, the North American Vertical Datum of 1988, or other datum referenced in the Flood Insurance Study report, or depth of the base flood, usually in feet, above the ground surface.

Cross Section

A line developed from topographic information across a floodplain at which a computation of flood flow has been made to establish a potential flood elevation. Cross-sections are shown on the Flood Boundary Floodway Map, Flood Insurance Rate Map, and-or Flood Profiles of a Flood Insurance Study.

Cubic feet per second (cfs)

Typical units used to express the rate of flow of surface water in open channels. One cf is approximately equal to 7.5 gallons per second.

Datum

A fixed starting point of a scale.

Discharge

The volume of water that passes a given location within a given period of time. Usually expressed in cubic feet per second (cfs).

Federal Emergency Management Agency (FEMA)

An independent agency of the Federal government, founded in 1979, which reports directly to the President. FEMA is responsible for identifying and mitigating natural and man-made hazards. The agency's mission is: To reduce loss of life and property and protect our nation's critical infrastructure from all types of hazards through a comprehensive, risk-based, emergency management program of mitigation, preparedness, response, and recovery.

Flood (also Flooding)

A general and temporary condition of partial or complete inundation of normally dry land areas. For flood insurance claim purposes, two or more structures must be inundated before flood damage will be covered

Flood Boundary Floodway Map (FBFM)

A pre-Map Initiatives floodplain management map that delineates the 100-year (1 percent annual chance) and 500-year (0.2 percent annual chance) floodplains, floodway, and cross sections.

Flood Insurance Rate Map (FIRM)

A map on which the 100-year (1% annual chance) and the 500-year (0.2% annual chance) floodplains, Base Flood Elevations, and risk premium zones (and floodway information on Map Initiatives FIRMs) are delineated to enable insurance agents to issue an accurate flood insurance policies to homeowners in communities participating in the National Flood Insurance Program.

Flood Insurance Study (FIS)

An examination, evaluation, and determination of flood hazards and, if appropriate, corresponding watersurface elevations. The resulting reports are used to develop Flood Insurance Rate Maps. Also known as a flood elevation study.

Flood Profile

A cross-sectional drawing showing the contiguous cross-sections along a stream, with ground elevations and potential flood elevations plotted.

Floodplain Management

The operation of the program of corrective and preventive measures for mitigating flood damage, including, but not limited to, emergency preparedness plans, flood-control works, and floodplain management regulations.

Floodplain or Flood Hazard Area

Floodplain, Flood Hazard Area or Flood-Prone Area

Any land area susceptible to inundation by water from any source.

Floodway

Channel of the stream plus any adjacent floodplain areas that must be kept free of encroachment so that a 100-year flood discharge can be conveyed without increasing the elevation of the 100-year flood by more than a specified amount (1 foot in most states).

HEC-2

A step backwater program developed by the US Army Corps of Engineers Hydrologic Engineering Center for use in calculating water-surface profiles for steady, gradually varied flow in natural or man-made channels.

Levee

A man-made structure, usually an earthen embankment, designed to contain, control or divert the flow of water in order to provide flood protection.

Manning's "n" Roughness Coefficient

Coefficient used to account for the friction caused by friction, vegetative, and/or man-made surfaces within a floodplain cross-section. The coefficient, n, is commonly used to represent flow resistance for hydraulic computations of flow and open channels. The procedure for selecting n values is subjective and requires judgment and skill that is developed primarily through experience. The expertise necessary for proper selection of n values can be obtained in part by examining characteristics of channels that have known or verified roughness coefficients. A table of Manning n values is available from t;H; pull-down menu in the Quick-2 program.

Map Repository

The location where a community's flood maps are kept; usually the local zoning and planning office.

Maps Service Center (MSC)

The Maps Service Center (MSC) distributes National Flood Insurance Program (NFIP) products including: Digital Flood Insurance Rate Maps (DFIRM), Flood Insurance Rate Maps (FIRM), Flood Insurance Studies (FIS), Digital Q3 flood data, Community Status Book, Flood Map Status Information Service (FMSIS), and Letters of Map Change (LOMC).

National Flood Insurance Program (NFIP)

Federal insurance program under which flood-prone areas are identified and flood insurance is made available to residents of participating communities that agree to adopt and enforce floodplain management ordinances to reduce future flood damage.

Normal Depth

The depth expected for a stream when the flow is uniform, steady, one-dimensional, and is not affected by downstream obstructions or flow changes. This is the usual calculation that is utilized to determine Base Flood Elevations for property or structures in approximate Zone A areas.

Overbank

The area of the cross section that is found outside of the channel bank stations on either side of the stream channel.

Peak Discharge

The peak volume of water that passes a given location within a given period of time. Usually expressed in cubic feet per second (cfs).

Perpendicular to Flow Path

Cross section should be plotted so that they are oriented in a manner that is perpendicular to the flow Path. Plotting cross-sections in this manner requires that the user examine the topography to determine the direction in which the water is most likely to flow in relation to different points along the proposed cross-section line. Typically, this can be achieved by ensuring that the cross-section line crosses each contour on the topographic map at or near a 90° angle.

Scale

A representative fraction of map distance to ground distance. Example: 1:12,000 is the representative fraction in which one unit of measure on the map is equal to 12,000 of the same units of measure on the ground. Federal Emergency Management Agency map scales are expressed in a ratio of map distance equal to a given number or feet on the ground.

Step-Backwater Analysis

Method used in Quick-2 (and other modeling programs) to analyze multiple cross-sections. Water-surface elevations are determined for all sections based on a given discharge. The initial water-surface elevation is automatically determined by the normal depth method or by a direct input of a water-surface elevation or depth.

Water-Surface Elevation

The height, in relation to the National Geodetic Vertical Datum of 1929 (or other datum, where specified) of floods of various magnitudes and frequencies in the identified floodplains of coastal or riverine areas.

Zone

A geographical area shown on Flood Hazard Boundary Map (FHBM) or a Flood Insurance Rate Map (FIRM) that reflects the severity or type of flooding in the area.

The following are not given in the FIS tutorial but are included here for your information:

Zone A

The flood insurance rate zone that corresponds to the 100-your floodplains that is determined in the Flood Insurance Study by approximate methods. Because detailed hydraulic analyses are not performed for such areas, no Base Flood Elevations or depths are shown within this zone. Mandatory flood insurance purchase requirements apply.

Zone A99

The flood insurance rate zone that corresponds to areas of the 100-year floodplains that will be protected by a Federal flood protection system where construction has reached specified statutory milestones. No Base Flood Elevations or depths are shown within the zone. Mandatory flood insurance purchase requirements apply.

Zone AE

[Note: In the tutorial, the following definition for Zone AE is accessed through clicking a link titled, "Zone AE and A1-A30.]

The flood insurance rate zone that corresponds to the 100-year floodplains that is determined in the Flood Insurance Study by detailed methods. In most instances, Base Flood Elevations derived from the detailed hydraulic analyses are shown at selected intervals within this zone. Mandatory flood insurance purchase requirements apply.

Zone AH

The flood insurance rate zone that corresponds to the areas of the 100-year shallow flooding with a constant water-surface elevation (usually areas of ponding) where average depths are between 1 and 3 feet. The Base Flood Elevations derived from the detailed hydraulic analyses are shown at selected intervals within this zone. Mandatory flood insurance purchase requirements apply.

Zone AO

The flood insurance rate zone that corresponds to the area of 100-year shallow flooding (usually sheet flow on sloping terrain) where average depths are between 1 and 3 feet. The depth should be averaged along the cross-section and then along the direction of flow to determine the extent of the zone. Average flood depths derived from the detailed hydraulic analyses are shown within this zone. In addition, alluvial fan flood hazards are shown as Zone AO on the Flood Insurance Rate Map. Mandatory flood insurance purchase requirements apply.

Zone AR

The flood insurance rate zone that results from the decertification of a previously accepted flood protection system that is being restored to provide protection from the 100-year or greater flood event.

Zone D

Designation on National Flood Insurance Program maps used for areas where there are possible, but undetermined, flood hazards. In areas designated as Zone D, no analysis of flood hazards has been conducted. Mandatory flood insurance purchase requirements do not apply, but coverage is available. The flood insurance rates for properties in Zone D are commensurate with the uncertainty of the flood risk.