



PDHonline Course G259W (2 PDH)

An Introduction to Passive Solar Buildings (Live Webinar)

Instructor: J. Paul Guyer, P.E., R.A., Fellow ASCE, Fellow AEI

2020

PDH Online | PDH Center

5272 Meadow Estates Drive
Fairfax, VA 22030-6658
Phone: 703-988-0088
www.PDHonline.com

An Approved Continuing Education Provider

**AN INTRODUCTION TO
PASSIVE SOLAR
BUILDINGS**

© J. Paul Guyer 2014 1

The presenter...


J. Paul Guyer, P.E., R.A.

Paul Guyer is a registered mechanical engineer, civil engineer, architect and fire protection engineer with over 35 years experience in the design of buildings and related infrastructure. For an additional 9 years he was a senior-level advisor to the California Legislature on infrastructure and capital outlay issues, including those involving solar energy and green-buildings design. He is a graduate of Stanford University and has held numerous national, state and local positions with the American Society of Civil Engineers, Architectural Engineering Institute and National Society of Professional Engineers.

© J. Paul Guyer 2014 2

PDHonline.org, Inc/PDH Center is a Registered Provider with The American Institute of Architects Continuing Education Systems. Credits earned on completion of this program will be reported to CES Records for AIA members. Certificates of Completion for non-AIA members are available on request.

This program is registered with the AIA/CES for continuing professional education. As such, it does not include content that may be deemed or construed to be an approval or endorsement by the AIA of any material of construction or any method or manner of handling, using, distributing, or dealing in any material or product. Questions related to specific materials, methods, and services will be addressed at the conclusion of this presentation.



© J. Paul Guyer 2014 3

Introduction

This course is intended as an introduction to principles and concepts underlying the design of buildings to *passively* utilize solar energy for heating. Here are some points for you to keep in mind as you go through the course material:

© J. Paul Guyer 2014 4

Introduction

□ This is an introduction to the *passive* solar technology that may be used to heat buildings. It is not about *active* technologies. Usually an optimal solution for a specific building and locale involves *passive* technology supplemented by *active* technologies. Active technologies are not part of this course. Passive technologies are. This will be discussed further.

© J. Paul Guyer 2014 5

Introduction

□ Utilization of passive solar energy to heat buildings is fundamentally an exercise requiring an understanding of :

- the fact that heat is transferred from outside to inside a building by conduction, convection and radiation, and
- the concept of heat sinks as a reservoir for heat storage.

© J. Paul Guyer 2014 6

Introduction

☐ Procedures for design of buildings to passively use solar energy for heating buildings may typically involve:

- use of shading devices to reduce heating by radiant (solar) energy in the summer and allow it in winter,
- utilize thermal convection (i.e. hot air rises) to maximize heating by convection in winter, and
- utilize thermal storage (mass-effect) to transfer excess heating capacity from daylight to nighttime hours.

© J. Paul Guyer 2014 7

Introduction

☐ This is an introductory course intended to tell you about basic systems and climate considerations underlying the passive utilization of solar energy to heat buildings. It is not intended to be a definitive design manual that can be used for feasibility studies, design analyses and building design.

© J. Paul Guyer 2014 8

Here is what we will discuss....

- ☐ Systems
- ☐ Climatic Considerations
- ☐ Sources of additional information and a few "rules of thumb"

© J. Paul Guyer 2014 9

Systems

There are six basic types of passive solar systems for buildings:

- ☐ Direct Gain Heating
- ☐ Daylighting
- ☐ Radiant Panels
- ☐ Thermosiphoning Air Panels
- ☐ Thermal Storage Walls
- ☐ Sunspaces

We will also address....

- ☐ Incremental Cooling Load

© J. Paul Guyer 2014 10

Systems

The basics....

The mechanisms by which heat is gained (or lost) by a space are:

- ☐ Conduction
- ☐ Convection
- ☐ Radiation


© J. Paul Guyer 2014 11

Systems

Direct Gain Heating

Direct gain buildings are passive solar heating systems in which sunlight is introduced directly to the living space through windows or other glazed apertures as indicated schematically in Figure 1. As with all passive solar systems, it is important that the apertures face south or near south in order to achieve high solar gains during the winter heating season and low solar gains during the summer cooling season.

© J. Paul Guyer 2014 12



Systems
Direct Gain Heating

Thermal storage mass is essential to the performance and comfort of direct gain buildings. A building that has inadequate mass will overheat and require ventilation, which entails a loss of heat that might otherwise have been stored for night time use. Generally, it is desirable to employ structural mass as a storage medium in order to take advantage of the improved economics associated with multiple use. Insulation should always be placed on the outside of massive elements of the building shell rather than on the inside in order to reduce heat losses without isolating the mass from the living space. Concrete floor slabs can contribute to the heat capacity of a building provided they are not isolated by carpets and cushioning pads. Heat losses from the slab can be limited by placing perimeter insulation on the outside of the foundation walls. If the structure is fairly light, the heat capacity can be effectively increased by placing water containers in the interior. A variety of attractive containers are available commercially.

© J. Paul Guyer 2014 14

Systems
Direct Gain Heating

An overhang, illustrated in Figure 1, is used to shade the solar aperture from the high summer sun while permitting rays from the low winter sun to penetrate and warm the inside of the building. In climates having particularly warm and sunny summers, an overhang may not be sufficient to prevent significant aggravation of the summer cooling load. Sky diffuse and ground reflected radiation enter the living space despite the presence of an overhang and must be blocked by external covers or internal shades. Using movable insulation on direct gain apertures has the advantage of reducing night time heat losses during the winter-as well as eliminating unwanted solar gains during the summer.

© J. Paul Guyer 2014 15

Systems
Direct Gain Heating

Direct gain buildings involve less departure from conventional construction than other types of passive solar systems and are therefore cheaper and more readily accepted by most occupants. However, they are subject to overheating, glare, and fabric degradation if not carefully designed; these problems can be minimized by distributing the sunlight admitted to the building as uniformly as possible through appropriate window placement and the use of diffusive blinds or glazing materials. When properly designed for their location, direct gain buildings provide an effective means of reducing energy consumption for space heating without sacrifice of comfort or aesthetic values.

© J. Paul Guyer 2014 16

Systems
Daylighting

Daylighting is not a passive solar heating technology but an adjunct to direct gain passive solar buildings that is available year-round. Pleasing uniform illumination can be achieved by using blinds that reflect sunlight toward white diffusive ceilings. The artificial lighting system in many buildings imposes a significant load on the cooling system that may be reduced by daylighting because the fraction of visible light in the solar spectrum is greater than the visible fraction of incandescent or fluorescent lighting.

© J. Paul Guyer 2014 17

Systems
Radiant Panels

Radiant panels are simple passive solar systems that are inexpensive and well suited as retrofits, particularly to metal buildings. A sketch of a radiant panel system is presented in Figure 2. Note that the solar aperture consists of one or more layers of glazing material placed over an uninsulated metal panel. The metal panel would ordinarily be a part of the building shell so that a retrofit is constructed by simply glazing an appropriate area on the south side of the structure. Any insulation or other poorly conducting material should be removed from the inner surface of the glazed portion of the metal panel to facilitate heat transfer to the interior.

© J. Paul Guyer 2014 18

Systems
Radiant Panels

FIGURE 2
RADIANT PANEL SYSTEM

WINTER SUN OVERHANG
SUMMER SUN
DOUBLE GLAZING
METAL PANEL
THERMAL STORAGE MASS (MASONRY)
WEATHER BARRIER
EXTERNAL INSULATION
EARTH BERM

© J. Paul Guyer 2014 19

Systems
Radiant Panels

Solar radiation is absorbed on the outer surface of the metal panel after passing through the glazings. The panel becomes hot and gives up heat to the interior by radiation and convection. Thermal mass must be included inside the building shell as with direct gain systems. Usually, only a concrete slab will be available before retrofitting a metal building and it may sometimes be necessary to add water containers to achieve the desired thermal capacitance. Radiant panels perform on a par with direct gain buildings and are likely to be less expensive when used as retrofits to metal buildings.

© J. Paul Guyer 2014 20

Systems
Thermosiphoning Air Panels

Thermosiphoning air panels (TAPs) are also appropriate for use on metal buildings either as retrofits or in new construction. Two configurations occur in practice and the first, which is referred to as a frontflow system, is illustrated in Figure 3. Again there are one or more glazing layers over an absorbing metal surface but, in this case, the metal panel is insulated on the back side. Heat transfer to the interior occurs via circulation vents cut through the metal panel and its insulation at the upper and lower extremes. Solar radiation absorbed on the outer surface of the panel is converted to heat and convected to the adjacent air which then rises due to buoyancy forces and passes through the upper vent into the living space. The warm air leaving the gap between the inner glazings and the absorber is replaced by cooler air from the building interior that enters through the lower vents. In this manner, a buoyancy driven loop is established and sustained as long as the temperature in the air gap exceeds that in the living space. Passive backdraft dampers or manually operated vent closures must be employed to prevent reverse circulation at night. Backdraft dampers are usually made of a lightweight plastic material suspended above a metal grid such that air flows freely in one direction but is blocked should the flow attempt to reverse.

© J. Paul Guyer 2014 21

Systems
Thermosiphoning Air Panels

FIGURE 3
FRONTFLOW TAP SYSTEM

WINTER SUN OVERHANG
SUMMER SUN
DOUBLE GLAZING
METAL PANEL
INSULATED STUD WALL
VENTS
THERMAL STORAGE MASS (MASONRY)
WEATHER BARRIER
EXTERNAL INSULATION
EARTH BERM

© J. Paul Guyer 2014 22

Systems
Thermosiphoning Air Panels

The second type of TAP configuration, illustrated in Figure 4, is called a backflow system. In a backflow system, the flow channel is behind the absorber plate rather than in front of it. An insulated stud wall is constructed a few inches behind the metal panel and vents are then cut at the top and bottom of the wall. Air in the flow channel thus formed is heated by convection from the back of the absorber panel and a circulation loop is established in the same manner as in a frontflow system.

© J. Paul Guyer 2014 23

Systems
Thermosiphoning Air Panels

FIGURE 4
BACKFLOW TAP SYSTEM

WINTER SUN OVERHANG
SUMMER SUN
DOUBLE GLAZING
METAL PANEL
INSULATED STUD WALL
VENTS
THERMAL STORAGE MASS (MASONRY)
WEATHER BARRIER
EXTERNAL INSULATION
EARTH BERM

© J. Paul Guyer 2014 24

Systems

Thermosiphoning Air Panels

TAPs have thermal storage requirements similar to those of direct gain and radiant panel systems. Generally speaking, the best performance will be obtained from passive solar systems associated with high heat capacity structures. Although a backflow TAP performs slightly better than a comparable system in the frontflow configuration, the difference is not significant and construction costs should govern any choice between the two. Both TAP configurations outperform radiant panels and direct gain systems with comparable glazings and thermal storage mass. This performance edge is due to the low aperture conductance of TAPs, which can be insulated to arbitrary levels, thereby limiting night time heat loss.

© J. Paul Guyer 2014

25

Systems

Thermal Storage Walls


A thermal storage wall is a passive solar heating system in which the primary thermal storage medium is placed directly behind the glazings of the solar aperture, as illustrated in Figure 5. The outer surface of the massive wall is painted a dark color or coated with a selective surface to promote absorption of solar radiation. Solar radiation absorbed on the outer surface of the wall is converted to heat and conducted (or convected in the case of the water walls) to the inner surface where it is radiated and convected to the living space. Heat transfer to the living space is sometimes augmented by the addition of circulation vents placed at the top and bottom of the mass wall. These vents function in the same manner as the vents in a TAP system except that only a portion of the solar heat delivered by the system passes through the vents.

© J. Paul Guyer 2014

26

Systems

Thermal Storage Walls



© J. Paul Guyer 2014

27

Systems

Thermal Storage Walls

A thermal storage wall provides an effective buffer between outside ambient conditions and the building interior; night time heat losses are reduced during the cold winter months, and during the summer, unwanted heat gains are limited. This moderating effect generally enables thermal storage walls to outperform direct gain systems. There are many types of thermal storage walls distinguished by the type of storage medium employed.

© J. Paul Guyer 2014

28

Systems

Thermal Storage Walls

Trombe Wall. A Trombe wall is a thermal storage wall that employs solid, high density masonry as the primary thermal storage medium. Appropriate thicknesses range from 6 to 18 inches depending on the solar availability at the building site. Sunny climates require relatively thicker walls due to the increased thermal storage requirements. The wall may be vented or unvented. A vented wall is slightly more efficient and provides a quicker warm up in the morning but may overheat buildings containing little secondary thermal storage mass in the living space.

© J. Paul Guyer 2014

29

Systems

Thermal Storage Walls

Concrete Block Wall. Ordinarily, a thermal storage wall would not be constructed of concrete building blocks, because solid masonry walls have a higher heat capacity and yield better performance. However, where concrete block buildings are very common they may offer opportunities for passive solar retrofits. The south facing wall of a concrete block building can be converted to a thermal storage wall by simply painting the block a dark color and covering it with one or more layers of glazing. Walls receiving this treatment yield a net heat gain to the building that usually covers the retrofit costs rather quickly. The relatively low heat capacity of concrete block walls is offset somewhat by the large amount of secondary thermal storage mass usually available in these buildings. Concrete floor slabs and massive partitions between zones help prevent overheating and otherwise improve the performance of concrete block thermal storage walls. Concrete block thermal storage walls may also be introduced during the construction of new buildings. For new construction, however, it is advisable to take advantage of the superior performance of solid masonry walls by filling the cores of the block in the thermal storage wall with mortar as it is erected. This process is inexpensive and the resulting performance increment covers the increased cost. The design procedures developed herein are applicable to 8-inch concrete block thermal storage walls with filled or unfilled cores.

© J. Paul Guyer 2014

30

Systems

Thermal Storage Walls

Water Wall. Water walls are thermal storage walls that use containers of water placed directly behind the aperture glazings as the thermal storage medium. The advantage over masonry walls is that water has a volumetric heat capacity about twice that of high density concrete; it is therefore possible to achieve the same heat capacity available in a Trombe wall while using only half the space. Furthermore, a water wall can be effective at much higher heat capacities than a Trombe wall because natural convection within the container leads to a nearly isothermal condition that utilizes all of the water regardless of the wall thickness. The high thermal storage capacity of water walls makes them especially appropriate in climates that have a lot of sunshine.

© J. Paul Guyer 2014

31

Systems

Sunspaces


There are many possible configurations for a sunspace but all of them share certain basic characteristics; a representative schematic is presented in Figure 6. Sunlight enters the sunspace through south facing glazing that may be vertical or inclined or a combination of the two and is absorbed primarily on mass surfaces within the enclosure; the mass may be masonry or water in appropriate containers and is generally located along the north wall and in the floor. The massive elements provide thermal storage that moderates the temperature in the enclosure and the rate of heat delivery to the living space located behind the north wall. Operable windows and circulation vents in the north wall provide for heat transfer by thermal convection from the sunspace to the living space. The north wall may be an insulated stud wall placed behind containers of water or a masonry wall through which some of the heat in the sunspace is delivered to the building interior by thermal conduction as occurs in a Trombe wall. A sunspace may be semi-enclosed by the main structure such that only the south facing aperture is exposed to ambient air, or may be simply attached to the main structure along the north wall of the sunroom, leaving the end walls exposed.

© J. Paul Guyer 2014

32

Systems

Sunspaces



© J. Paul Guyer 2014

33

Systems

Sunspaces

The temperature in a sunspace is not thermostatically controlled but is generally moderate enough for human habitation during most of the day and appropriate for growing plants year round. Amenities are thus provided that compensate for the somewhat higher cost of sunspaces relative to other types of passive solar heating systems.

© J. Paul Guyer 2014

34

Systems

Incremental Cooling Load

Unfortunately, not all of the heat delivered to the living space by a passive solar heating system is useful to the occupants. During the winter heating season, part of the delivered solar energy will cause the building to overheat unless ventilation is employed to limit the indoor temperature. It is to be expected that some overheating will occur in most passive solar buildings, but too much excess heat is indicative of a poor design: it may be that the solar aperture is too large or that inadequate thermal storage mass has been provided. During the summer cooling season, a passive solar heating system continues to function although the increased solar elevation angle reduces the radiation flux transmitted through the glazings, particularly if an overhang is employed. However, all heat delivered to the building during the cooling season is unwanted and must be removed either by ventilation or by evaporative or vapor compression cooling systems. A poorly designed passive heating system can significantly aggravate the summer cooling load of a building. The sum of all unwanted heat delivered to a building by the passive heating system is referred to as the incremental cooling load. This is clearly an important parameter because it represents the cooling penalty associated with various passive solar designs.

© J. Paul Guyer 2014

35

Now we will look at climatic considerations....

- Characteristic Weather Parameters
- Climate and Conservation Measures
- Solar Availability
- Guidelines for Schematic Design

© J. Paul Guyer 2014

36

Climatic Considerations
Characteristic Weather Parameters

First, Characteristic Weather Parameters....

© J. Paul Guyer 2014 37

Climatic Considerations
Characteristic Weather Parameters

This discussion is based on two weather parameters that, in certain combinations, may be used to characterize climates with respect to the potential effectiveness of conservation and passive solar measures in reducing energy consumption for space heating.

© J. Paul Guyer 2014 38

Climatic Considerations
Characteristic Weather Parameters

The first of these important parameters is the heating degree days, which is represented by the symbol DD and has units of deg.F-day. DD is calculated by summing the difference between the base temperature and the outside ambient temperature over each hour in the time period of interest and dividing the result by 24 hr/day; all negative terms are omitted from the sum. The base temperature is the thermostat setpoint adjusted to account for the presence of internal heat sources; the time period of interest is usually one month or one year. This method of calculating DD differs from the American Society of Heating, Refrigerating and Air-Conditioning Engineers (ASHRAE) approach and is recommended because it yields better accuracy when applied to the analysis of passive solar buildings. Furthermore, the hourly data required for such a calculation is available in the Typical Meteorological Year (TMY) data base. The heating degree days is an important weather parameter because the amount of heat lost from a building during a particular time period is directly proportional to DD, i.e., if a building is moved from one location to another having twice as many degree days, the heat loss from the building will double.

© J. Paul Guyer 2014 39

Climatic Considerations
Characteristic Weather Parameters

The second important weather parameter is VT2, the amount of solar energy transmitted through a vertical, south facing, double glazed aperture during a specific time period. The V in VT2 stands for vertical, the T indicates transmitted radiation, and the 2 represents the two glazing layers. The parameter VT2 is important because it quantifies the solar resource available for passive space heating.

In the following discussion, combinations of VT2 and DD are used to characterize climates with regard to the relative importance of conservation and passive solar measures for reducing auxiliary heat consumption in buildings.

© J. Paul Guyer 2014 40

Climatic Considerations
Characteristic Weather Parameters

Second, Climate and Conservation Measures....

© J. Paul Guyer 2014 41

Climatic Considerations
Climate and Conservation Measures

The fraction of the monthly heating load of a building that can be met by passive solar strategies depends on certain characteristics of the building design, and for double glazed systems, which are by far the most common, on the ratio VT2/DD. For this discussion, it is sufficient to know that the parameter VT2/DD provides an accurate measure of the passive solar potential of a given climate during any selected month. It follows that by considering the value of VT2/DD for each month in the heating season, it is possible to assess the passive solar potential of the climate for the full annual cycle. One way to do this might be to average VT2/DD over all months in the heating season, but that approach would ignore the fact that it is more important to have high solar heating fractions in cold months with high values of DD than it is in warm months with low values of DD. The solution to this dilemma is to determine the degree day weighted average of VT2/DD.

© J. Paul Guyer 2014 42

Climatic Considerations
Climate and Conservation Measures

It follows that in climates having low values of weighted average of VT2/DD conservation measures such as insulation, storm windows, weather stripping, etc., will be more important than in climates having high values. If only a small portion of the building load can be displaced with solar energy, then reduction of that load through the use of conservation measures clearly becomes a top priority. A map of the continental United States with contours of constant weighted average of (VT2/DD) is presented in Figure 7. The three contour lines divide the map into four climate regions that are referred to as mild (MI), moderate (MO), harsh (HA), and very harsh (VH). General descriptions of these climate regions and qualitative comments regarding regionally appropriate design are presented in the next four subsections.

© J. Paul Guyer 2014

43

Climatic Considerations
Climate and Conservation Measures

FIGURE 7
PRINCIPAL CLIMATE REGIONS



© J. Paul Guyer 2014

44

Climatic Considerations
Climate and Conservation Measures
Mild Climates

First, some comments on passive solar considerations in **Mild Climates**...



© J. Paul Guyer 2014

45

Climatic Considerations
Climate and Conservation Measures
Mild Climates

The mild climate region includes the southern third of California and Arizona, small parts of the southern extremes of New Mexico, Texas, and Louisiana, and most of the Florida peninsula.

In the mild region the winter heating load varies from small to nil and in any case, there is plenty of sunshine available to meet whatever loads do arise. Generally, the small heat loads can be displaced with inexpensive radiant panels or direct gain systems having relatively small solar collection apertures. However, summer cooling loads in this region can be quite high, usually exceeding the winter heating load several times over.

© J. Paul Guyer 2014

46

Climatic Considerations
Climate and Conservation Measures
Mild Climates

It is therefore particularly important to assure that the incremental cooling load associated with the passive heating system does not negate the small savings realized during the winter heating season. The use of defensive countermeasures such as adjustable shades and shutters that shield the solar aperture from direct and diffuse sunlight during the cooling season is essential. The term defensive cooling refers to strategies or devices that prevent excess heat from entering a building, in contrast to procedures for removing such heat with air conditioning equipment after it has gained entry. Because of the high SHFs obtainable in the mild region, conservation measures are not as important as in regions further north.

© J. Paul Guyer 2014

47

Climatic Considerations
Climate and Conservation Measures
Moderate Climates

Now, some comments on passive solar considerations in **Moderate Climates**...



© J. Paul Guyer 2014

48

Climatic Considerations
Climate and Conservation Measures
Moderate Climates

The moderate region includes most of California, the southern half of Nevada, the central third of Arizona, and most of New Mexico, Texas, Louisiana, Mississippi, Alabama, Georgia, and South Carolina. The Florida panhandle and most of the North Carolina coast are also included.

Thermal storage walls, sunspaces, thermosiphoning air panels, and direct gain systems are all appropriate in this region. The solar apertures will be larger than in the mild region and more thermal insulation will be required. Defensive cooling strategies are also important to overall performance.

© J. Paul Guyer 2014

49

Climatic Considerations
Climate and Conservation Measures
Harsh Climates

Now, some comments on passive solar considerations in **Harsh Climates**....



© J. Paul Guyer 2014

50

Climatic Considerations
Climate and Conservation Measures
Harsh Climates

The harsh region includes most of Washington, Oregon, Idaho, Nevada, Wyoming, Utah, Colorado, Nebraska, Kansas, Oklahoma, Missouri, Arkansas, Kentucky, Tennessee, Virginia, and North Carolina. Northern parts of Arizona, New Mexico, Texas, Mississippi, Alabama, Georgia, and South Carolina are also included as well as southern parts of Montana, South Dakota, Iowa, Illinois, Indiana, and West Virginia. Finally, the harsh region includes coastal areas in Massachusetts, Rhode Island, New York, New Jersey, Maryland, and all of Delaware.

At the northern extremes of the harsh region, night insulation should be considered on direct gain apertures. Otherwise, all passive systems may be adequate in this region; heating loads are substantial making conservation measures very important. Despite the large heating loads, defensive cooling strategies are still required to assure positive net energy savings.

© J. Paul Guyer 2014

51

Climatic Considerations
Climate and Conservation Measures
Very Harsh Climates

Now, some comments on passive solar considerations in **Very Harsh Climates**....



© J. Paul Guyer 2014

52

Climatic Considerations
Climate and Conservation Measures
Very Harsh Climates

The very harsh region includes all of North Dakota, Minnesota, Wisconsin, Michigan, Ohio, Vermont, New Hampshire, and Maine; most of Montana, South Dakota, Iowa, Illinois, Indiana, West Virginia, Connecticut, Pennsylvania, and Massachusetts; and parts of Washington, Idaho, Wyoming, Nebraska, Kentucky, Virginia, Maryland, New Jersey, and Rhode Island.

Near the boundary between the harsh and very harsh regions or in areas with greater than average sunshine, direct gain systems without night insulation may still be viable provided the aperture is kept fairly small. Thermal storage walls and sunspaces will function well in this region although night insulation may be desirable near the northern boundary; TAPs are a good choice because arbitrarily high levels of fixed insulation can be placed between the collector surface and the living space. Heavy use of conservation measures is critical to performance in the very harsh region. Defensive cooling strategies, though less of a concern than in regions with milder winter climates, should not be ignored.

© J. Paul Guyer 2014

53

Climatic Considerations
Solar Availability

Third, **Solar Availability**....

© J. Paul Guyer 2014

54

Climatic Considerations
Solar Availability

As previously discussed, the parameter VT2 provides a measure of the availability of solar radiation as a space heating resource during a specified time period. If VT2 were evaluated for the duration of the winter heating season the result would provide some indication of the potential of the site for passive solar heating applications. However, it is more important to have high solar availability during the colder months of the heating season than during the warmer months, and the straight summation involved in evaluation of VT2 does not reflect this fact. A better measure of the effective solar availability is obtained by taking the degree day weighted average of the monthly VT2s that occur during the heating season.

© J. Paul Guyer 2014

55

Climatic Considerations
Solar Availability


A map of the continental United States with contours of constant weighted average of VT2 is presented in Figure 8. The four contours divide the map into five regions that are labeled most sunny (MS), very sunny (VS), sunny (SU), cloudy (CL), and very cloudy (VC). These five regions cut across the four principal climate regions defined in Figure 7 and form subregions that are related to the appropriate size of solar apertures. As a general rule, the sunnier subregions of a particular principal climate region should have the larger solar apertures.

© J. Paul Guyer 2014

56

Climatic Considerations
Solar Availability

FIGURE 8
SOLAR AVAILABILITY REGIONS




© J. Paul Guyer 2014

57

Climatic Considerations
Solar Availability
Most Sunny Region

First, some comments on Solar Availability in the Most Sunny Region....



© J. Paul Guyer 2014

58

Climatic Considerations
Solar Availability
Most Sunny Region


This region is limited to the desert southwest and includes major parts of Nevada, Arizona, and New Mexico. Subregions in which the most sunny region overlaps the harsh region are ideal for passive solar heating because of the coincidence of a substantial heating load and excellent solar availability. The most sunny/moderate subregion is also quite good for passive solar heating.

© J. Paul Guyer 2014

59

Climatic Considerations
Solar Availability
Very Sunny Region

Now, some comments on Solar Availability in the Very Sunny Region....



© J. Paul Guyer 2014

60

Climatic Considerations
Solar Availability
Very Sunny Region


The very sunny region forms a complex crescent in the Mountain, Pacific and Plains states and contains parts of California, Nevada, Utah, Colorado, Arizona, South Dakota, Texas, Oklahoma, Kansas and Nebraska. It forms a large, very sunny/harsh subregion in which passive solar applications are very beneficial.

© J. Paul Guyer 2014

61

Climatic Considerations
Solar Availability
Sunny Region

Now, some comments on Solar Availability in the **Sunny Region**....



© J. Paul Guyer 2014

62

Climatic Considerations
Solar Availability
Sunny Region


The sunny region forms a still larger crescent about the very sunny region, and includes parts of Florida, Alabama, Georgia, South Carolina, North Carolina, and Virginia. The sunny area cuts completely across the country from North to South and forms subregions with all four principal climate zones. A broad range of passive solar designs is viable across these subregions.

© J. Paul Guyer 2014

63

Climatic Considerations
Solar Availability
Cloudy Region

Now, some comments on Solar Availability in the **Cloudy Region**....



© J. Paul Guyer 2014

64

Climatic Considerations
Solar Availability
Cloudy Region

The cloudy region also traverses the country from north to south and forms four types of subregions among which many passive designs are feasible. Parts of the Pacific northwest, the Midwest, and the eastern seaboard are included in the cloudy region.

© J. Paul Guyer 2014

65

Climatic Considerations
Solar Availability
Very Cloudy Region

Now, some comments on Solar Availability in the **Very Cloudy Region**....



© J. Paul Guyer 2014

66

Climatic Considerations
Solar Availability
Very Cloudy Region

The very cloudy region includes only the extreme Pacific Northwest and the central to eastern Great Lakes area. The Great Lakes area, where the very cloudy region overlaps the very harsh region, is the poorest location in the continental United States for passive solar heating. The Pacific northwest area overlaps the Harsh climate region and is slightly better suited for passive solar applications.

Climatic Considerations
Guidelines for Schematic Design

We will now look at **Guidelines for Schematic Design** that are related to the climate regions appearing in Figures 7 and 8 and discussed above.

The objective during schematic design is to develop a rough idea of what the final building will be like. The designer is not concerned with detail at this point but seeks only to establish the basic shape, dimensions, materials, window areas, and insulation levels that will characterize the design; in these procedures, the characteristics of the passive solar heating system are added to the list of more traditional architectural concerns.

Climatic Considerations
Guidelines for Schematic Design
Building Shape and Orientation

Passive solar buildings are usually elongated in the east-west direction so that a large south-facing surface is presented to the low winter sun for solar heating, and small east and west-facing surfaces are presented to the northerly rising and setting summer sun to reduce unwanted solar gains. The aspect ratio (east-west dimension divided by north-south dimension) should be at least 5/3.

Ideally, passive solar buildings should be no more than two zones deep in the north-south direction. The two zone limit on depth generally allows solar heat collected on the south side of the building to be transported for use to the north side, thereby improving thermal performance. Multi-story buildings are well suited to passive solar design, particularly if the above recommendations on aspect ratio and depth are observed, because of the large vertical surface that may be presented to the winter sun for solar absorption.

Climatic Considerations
Guidelines for Schematic Design
Building Shape and Orientation

Orientations that depart from true south by up to 30 degrees are permissible; performance penalties will usually be less than 10 percent. An easterly bias is preferred in applications that require a rapid warm up in the morning, whereas a westerly bias will sometimes improve the performance of buildings that are occupied in the evening because of the improved phasing of heat source and heat load.

Climatic Considerations
Guidelines for Schematic Design
East, West and North Windows

Windows not facing south should be kept small while complying with local building codes. Particularly in the colder climates, it is best to place most of the non-south window area on the east or west side of the building to take advantage of winter solar gains available during the early morning and late afternoon.

All windows, including those facing south, should have at least two glazing layers, and in the harsh and very harsh regions, triple or even quadruple glazing should be considered. Especially in the warmer climates, drapes or better still, movable opaque covers or shades, as described as thermal shutters and shades, are recommended as means to prevent unwanted sunlight from entering the windows during the summer.

Climatic Considerations
Guidelines for Schematic Design
Passive Heating System Characteristics

The interaction between a passive heating system and its environment is a complex process that involves many subtle phenomena. The complexity of the interaction makes it difficult to determine exactly what type of passive system will perform best in a given climate. Ultimately, detailed design analysis calculations may be required to make the final decision. However, a few generalizations may be cited that are useful for selecting candidate systems during the schematic phase of design.

Climatic Considerations
Guidelines for Schematic Design
Passive Heating System Characteristics

The general rules for system selection are based on the steady state conductance of the passive solar aperture. The aperture conductance is the amount of heat that would be lost through the solar aperture if the outside ambient temperature were maintained at 1deg.F below the indoor temperature for a period of one hour. It is generally true that systems with low values of steady state conductance are better suited for use in areas having relatively severe winter climates than are systems with larger aperture conductances. The climate regions based on the importance of conservation measures that are illustrated in Figure 7 provide a convenient measure of winter severity.

© J. Paul Guyer 2014

73

Climatic Considerations
Guidelines for Schematic Design
Passive Heating System Characteristics

The selection process based on aperture conductance may be further refined by the observation that it is also more important to have a small steady state conductance in regions that receive relatively little sun; the solar availability contour map in Figure 8 is useful in making this secondary assessment. In summary, passive solar systems having low aperture conductances are recommended for use in regions having severe winter climates with little sunshine.

© J. Paul Guyer 2014

74

Climatic Considerations
Guidelines for Schematic Design
Sizing Overhangs

The purpose of a fixed overhang is to reduce unwanted solar gains during the summer while allowing the low winter sun to illuminate the solar aperture and provide heat to the building interior. Sizing an overhang is a difficult problem because the heating season is not symmetrical about the winter solstice, but tends to be displaced toward the new year. Therefore, a design that provides adequate protection from overheating in the fall may tend to reduce the amount of solar energy available for needed space heating in late winter or spring. Since an overhang does not provide protection from sky diffuse or ground reflected radiation, it is often necessary to provide additional countermeasures to prevent overheating during the cooling season. For this reason, the currently accepted design practice is to size an overhang such that the performance of the passive heating system is minimally affected, and employ additional countermeasures against overheating as required.

© J. Paul Guyer 2014

75

Climatic Considerations
Guidelines for Schematic Design
Insulation Levels


Starting point values for thermal insulation are recommended on the basis of principal climate region and building size, and geometry. The R-values (thermal resistance) of walls, including installed insulation and other layers, should lie in the intervals consistent with the intervals indicated in Figure 9.

© J. Paul Guyer 2014

76

Climatic Considerations
Guidelines for Schematic Design
Insulation Levels

**FIGURE 9
PRINCIPAL CLIMATE REGIONS
R VALUES**



© J. Paul Guyer 2014

77

Climatic Considerations
Guidelines for Schematic Design
Insulation Levels

Larger buildings derive a greater benefit from incidental heating by internal sources because of the reduced external surface area relative to the heated floor area. For three reasons, it is common practice to employ higher levels of insulation in the ceiling than the wall:

- a. It is cheaper to insulate the ceiling than the wall.
- b. Stratification causes larger heat loss rates per unit area of ceiling than per unit wall area.
- c. Solar gains on roofs during the summer can cause unwanted heating of the living space beyond that caused by high ambient air temperature.

© J. Paul Guyer 2014

78

Climatic Considerations
 Guidelines for Schematic Design
Insulation Levels

Heat losses through building perimeters and fully bermed basement walls are limited by contact with the soil so that insulation levels need not be so high as for exposed external walls. Ordinarily, floors are not insulated so as to assure that pipes located below do not freeze. Because of widely varying conditions beneath ground level floors, it is difficult to recommend specific insulation levels. The insulation levels recommended above are intended only as starting point values. Design analysis calculations should be performed before fixing any important design variables.

© J. Paul Guyer 2014

79

Climatic Considerations
 Guidelines for Schematic Design
Infiltration

Many older buildings have infiltration rates as high as 1.5 air changes per hour (ACH). A reduction to 1.0 ACH may be achieved by employing a plastic vapor barrier; taking care to seal all joints and foam any cracks will generally further reduce the infiltration rate to 0.5 ACH. It is strongly recommended that the infiltration rate be limited to 0.5 ACH for both new construction and retrofits whenever possible. Since extremely low rates may be hazardous to the occupants' health due to the accumulation of indoor pollutants, further reductions in infiltration heat loss should be attempted only through the use of window heat recovery units. Extensive use of these units can yield effective infiltration rates as low as 0.187 and under certain circumstances, the additional expense involved may be justifiable.

© J. Paul Guyer 2014

80

Climatic Considerations
 Guidelines for Schematic Design
Solar Collection Area


The solar collection areas indicated here are intended to illustrate starting point values for a design analysis procedure. Figure 10 is an example of solar aperture area in percent of floor space. Remember, this is only for illustration purposes. Large apertures occur where high solar availability coincides with a large heat load. Small apertures occur where the solar availability is low or the heat load is small.) These aperture sizes, used in conjunction with the recommended insulation and infiltration levels, will yield a payback period of ten years for some systems.

© J. Paul Guyer 2014

81

Climatic Considerations
 Guidelines for Schematic Design
Solar Collection Area

FIGURE 10
SOLAR APERTURE AREA IN PERCENT OF FLOOR SPACE
 (ILLUSTRATIVE EXAMPLE FOR ONE TYPE OF SYSTEM)



© J. Paul Guyer 2014

82

Climatic Considerations
 Guidelines for Schematic Design
Thermal Storage Mass

The amount of thermal storage mass required per square foot of solar aperture depends primarily on the solar availability at the building site. The relative solar availability in the continental United States is given by the contour map in Figure 8.

Masonry thermal storage walls and sunspaces with masonry common walls generally employ a wall thickness of about 12 inches of high density material. This thickness is quite appropriate in the sunny region and to a large extent, in the adjacent cloudy and very sunny regions. However, in the most sunny region a wall thickness of 18 inches should be employed to protect against overheating and fully utilize the available resource. In the very sunny region, wall thicknesses may range from 12 inches to 18 inches depending on which boundary the building site is nearest.

© J. Paul Guyer 2014

83

Climatic Considerations
 Guidelines for Schematic Design
Thermal Storage Mass

At the other extreme, mass walls in the very cloudy region need only be 6 inches thick and in the adjacent cloudy region, thicknesses may range from 6 inches to 12 inches depending on position relative to the boundaries. When water containers are used for thermal storage, either in sunspaces or thermal storage walls, equivalent thicknesses comparable to those recommended for masonry walls are appropriate in all solar availability regions; however, because the heat capacity of water is roughly twice that of high density masonry, significant downward revisions may be permissible.

Direct gain apertures, radiant panels, and TAPs all use interior mass for heat storage. Ideally, the interior mass should have a high density and be distributed in thicknesses of 2 inches to 6 inches. Appropriate area ratios are 3 in the very cloudy region, 3 to 6 in the cloudy region, 6 in the sunny region, 6 to 9 in the very sunny region and 9 in the most sunny region. Equivalent or somewhat smaller volumes of water may be used instead of masonry in lightly constructed buildings.

© J. Paul Guyer 2014

84

And here is a good starting point for more information....DTIC

The screenshot shows the DTIC Online interface. At the top, there's a navigation bar with links like Home, Registration, DTIC A-Z, Submit Documents, Interest Areas, and Customer Support. Below that is a search bar with a dropdown menu for 'DOD Sites & Collections' and a 'GO' button. The main content area displays details for document ADA136229, including its title 'Passive Solar Design Procedures for Naval Installations', author 'Wray, W O', and corporate author 'LOS ALAMOS NATIONAL LAB NM'. There are also links for 'Full Text (pdf) Availability' and 'Order Paper Copy'.

© J. Paul Guyer 2014 85

And here is a good starting point for more information....DTIC

Abstract:

The energy efficiency of buildings at Naval installations can be greatly improved through the use of passive solar heating strategies. These strategies may be applied to many existing buildings that are suitable for retrofit and are universally applicable to new construction. The purpose of this design procedure is to provide the tools required by professionals involved in building design and/or evaluation who wish to improve the energy efficiency of buildings by use of passive solar heating. Three types of tools are provided. First, a general discussion of the basic concepts and principles of passive solar heating is presented to familiarize the reader with this relatively new technology. Second, a set of guidelines are presented for use during schematic design that will enable the user to quickly define a building that will perform in a cost-effective manner at the intended building site. Finally, a quantitative design-analysis procedure is presented that provides the user with an accurate estimate of the auxiliary heating requirements of a given passive solar design. This procedure is presented that provides the user with an accurate estimate of the auxiliary heating requirements of a given passive solar design. This procedure may be used to refine or fine tune a preliminary design based on the schematic-design guidelines or may be used during proposal evaluation to compare the merits of various candidate designs.

© J. Paul Guyer 2014 86

Here is another good source of more information....NTIS

The screenshot shows the NTIS website interface. At the top, there's a navigation bar with links like Home, About, NTIS Database, Publications & Subscriptions, Federal Services, and Contact. Below that is a search bar with a 'SEARCH NTIS' button. The main content area displays details for document AD-A198 2804, including its title 'Design Calculation Procedure for Passive Solar Houses at Navy Installations in Warm California Climates, Volume V - Preliminary rept. Apr 80-Sep 81', author 'Lumsdaine E. Lumsdaine', and contract number 'N62583-79-MR-605'. There are also links for 'Product Type: Technical report' and 'NNTIS Best Sellers'.

© J. Paul Guyer 2014 87

Here are some useful publications....

- *Designing Low-Energy Buildings with Energy-10 Software Integrating Daylighting, Energy Efficient Equipment, and Passive Solar Design in Commercial Institutional and Residential Buildings* available from the Sustainable Buildings Industry Council (SBIC).
- *E Source Electronic Encyclopedia* Rocky Mountain Institute. Available from E Source
- *Passive Solar Design Strategies: Guidelines for Home Building* available from SBIC.
- *Proceedings of the National Passive Solar Conferences*. American Solar Energy Society (ASES).
- *Sustainable Building Sourcebook, Passive Solar Guidelines*
- Evaluations of the performance of a number of passive solar heated buildings are available through the *U.S. Department of Energy Exemplary Building Program*. A description of the projects for building energy analysis is available through the National Renewable Energy Laboratory (NREL). (NREL, Public Affairs Office; 1617 Cole Boulevard, Golden, Colorado 80401)

© J. Paul Guyer 2014 88

Here are some useful analytical tools....

To analyze the performance of small residential-type, skin-load dominated passive solar heated buildings, use: *Guidelines for Home Building with BuilderGuide software*. This is a simple computer software tool (in a Windows format) for evaluating the solar savings fraction of a building design. The program is available from the Sustainable Buildings Industry Council (SBIC).

To analyze the performance of small residential, institutional, and commercial passive solar heated buildings (with one or two thermal zones), use: *Passive Solar Design Strategies: Guidelines for Home Building & ENERGY-10 software*. The solar heating performance of simple commercial buildings of up to approximately 10,000 square feet can be evaluated using the *Strategies* and the *ENERGY-10* hourly simulation program.

To analyze the performance of large, internal-load dominated, commercial and institutional buildings, see: *DOE 2.1e* (or latest). The solar heating performance of larger and more complex buildings requires the use of a more powerful computer program. Multi-zone programs developed by the government (Department of Energy) such as *DOE2.1* and *EnergyPlus* are available from the Simulation Research Group, Lawrence Berkeley National Laboratory.

© J. Paul Guyer 2014 89

Here are some "rules of thumb"....

- South-facing passive storage walls in direct sunlight should have a minimum of 30-lb water storage or 150-lb masonry (concrete) storage per square foot of south vertical glazing. If the storage media is not located in direct sunlight, four times this amount will be needed. Others recommends at least 5-6 gallons water storage (about 45 lb) per square foot of south glass.
- Shading of south windows should be used to reduce summer and fall overheating. One effective geometry is a roof overhang which will just shade the top of the window at noon (solar time) sun elevation of 45 deg. and will fully shade the window at noon sun elevation of 78 deg. F.
- The best thickness of a Trombe wall is from 12 to 16 inches. The masonry should have a high density - at least 100 lb/ft³. Thermocirculation vents can be used to increase daytime heating but will not increase nighttime minimums. Vents should have lightweight passive backdraft dampers or other means of preventing reverse flow at night.

© J. Paul Guyer 2014 90

Here are some "rules of thumb"....

- ❑ Two to three square feet of south-facing double glazing should be used for each Btu/deg. F-hr of additional thermal load (i.e., exclusive of the glazing). This will give 70% to 80% solar heating in northern New Mexico (Los Alamos) for a building kept within the range of 65 deg. F to 75 deg. F.
- ❑ For a well-insulated space in 40 deg. N latitude in cold climates (outdoor temperature = 20 deg. F to 30 deg. F) the ratio of south glazing to floor area is in range 0.20 to 0.25 to maintain an average space temperature of 68 deg. F over 24 hours (e.g., a 200 ft² floor space needs 40-50 ft² of south glazing). In temperate climates (35 deg. F to 45 deg. F outdoor temperature) use ratios in the range 0.11-0.17.
- ❑ For greenhouses: To determine solar gain: $S = 1200 \text{ Btu/ft}^2$ of glazing per clear day, $S = 700 \text{ Btu/ft}^2$ per average day. Double glaze only south wall. Insulate all opaque surfaces to R20, outside foundation to frost line to R10, minimize infiltration with caulking. Thermal mass = 5 gal of water or 1-2/3 ft³ of gravel per square foot of glazing. If storage is thermally isolated from greenhouse, air should be moved at 10 ft³/min per square foot of glazing through the storage.

© J. Paul Guyer 2014

91

Now, to summarize....

© J. Paul Guyer 2014

92

Summary

There are six basic types of passive solar systems for buildings:

- ❑ Direct Gain Heating
- ❑ Daylighting
- ❑ Radiant Panels
- ❑ Thermosiphoning Air Panels
- ❑ Thermal Storage Walls
- ❑ Sunspaces

© J. Paul Guyer 2014

93

Summary

We looked at these climatic considerations....


- ❑ Characteristic Weather Parameters
- ❑ Climate and Conservation Measures
- ❑ Solar Availability
- ❑ Guidelines for Schematic Design

© J. Paul Guyer 2014

94

Summary

FIGURE 7
PRINCIPAL CLIMATE REGIONS




© J. Paul Guyer 2014

95

Summary

FIGURE 8
SOLAR AVAILABILITY REGIONS



© J. Paul Guyer 2014

96

Summary

And we looked at these guidelines for schematic design....

- Building Shape and Orientation
- East, West and North Windows
- Passive Heating System Characteristics
- Sizing Overhangs
- Insulation Levels
- Infiltration
- Solar Collection Area
- Thermal Storage Mass

© J. Paul Guyer 2014

97

Thank you for your time!
QUESTIONS??

PDHonline.org, Inc., / PDH Center

Info@PDHonline.org 703-988-0088

© J. Paul Guyer 2014

98



That's all folks!

© J. Paul Guyer 2014

99